

# Technical APPLICATION Guide

## Double Unit Warblers SC628WR, SC628JWR, SC628FW, SC628FJW

The double unit warbler models require two audible alarm units to generate the alternating warble sound. The following combinations of models are possible:

### Medium Loud - Fast Warble:

Use SC628DR with SC628WR (alternating 1900 Hz & 2900 Hz)

Use SC628HR with SC628WR (alternating 2900 Hz & 4500 Hz)

### Medium Loud - Slow Warble:

Use SC628DR with SC628JW (alternating 1900 Hz & 2900 Hz)

Use SC628HR with SC628JW (alternating 2900 Hz & 4500 Hz)


### Soft - Fast Warble:

Use SC628ER with SC628FW (alternating 1900 Hz & 2900 Hz)

### Soft – Slow Warble:

Use SC628ER with SC628FJW (alternating 1900 Hz & 2900 Hz)

### Wiring Diagram:



Note: The “R” in the part number means RoHS compliant. It is okay to use the same part number but without the “R”. For example, SC628W and SC628WR.